

IN THE BOX

Ventus V2000X4 4G LTE Router
Ventus Antenna
Ethernet cable
Power supply



1x Antenna



1x Ethernet cable



1x Power supply




QUICK TIP: The V2000X4 has a powerful magnetic base - enabling you to affix it, vertically or horizontally, to any magnetic surface.

1

Plug Ethernet cable into LAN port on Ventus router.

Plug the other end of the Ethernet cable into the customer device.



2

Securely fasten the antenna via both TNC connectors to MA and AuxA ports.



- 3** Plug in power adapter.




QUICK TIP: To **soft reset** your router, depress the small button to the left of the power input with a pin or paper clip while the unit is powered on.



QUICK TIP: To **completely power down** the router, first unplug the unit from electrical outlet and then depress the small button to the left of power input with a pin or paper clip.

- 4** Wait for CELL LINK light to persistently turn GREEN. This may take up to 5 minutes.



QUICK TIP: Use the signal indicator lights  on the front to determine the best placement for the antenna.

For support please call
Ventus Technical Support Center at 1-800-620-3586